

ATC SURVEILLANCE MINIMUM ALTITUDE CHART - ICAO

VAR 4° E

AD ELEV 1907 FT

INNSBRUCK  
ÖSTERREICH AUSTRIA


RADAR TOWER 128.975  
120.100

TRANSITION ALTITUDE  
10000

Lateral limits of minimum vectoring altitude sectors are provided as attachment to this chart.

Minimum flight altitudes (FT AMSL / FL) applicable for surveillance controlled aircraft within controlled airspace; values in brackets refer to minimum flight altitudes in uncontrolled airspace providing adequate obstacle clearance.

The chart may only be used for cross-checking of assigned altitudes whilst under radar control.



CHANGE: RADAR FREQ; EDITORIAL

Bezeichnung Seitliche Begrenzungen
Name Lateral limits
<p><b>EDS10</b></p> <p>47 55 00.0000N 012 47 50.0000E - 47 51 46.0000N 012 50 58.0000E - 47 50 24.0000N 012 48 24.0000E - 47 52 18.0000N 012 42 54.0000E - 47 55 00.0000N 012 47 50.0000E</p>
<p><b>EDS11</b></p> <p>47 55 03.0000N 012 39 51.0000E - 47 52 18.0000N 012 42 54.0000E - 47 48 53.0000N 012 37 52.0000E - 47 51 17.0000N 012 34 46.0000E - 47 53 52.0000N 012 35 29.0000E - 47 55 03.0000N 012 39 51.0000E</p>
<p><b>EDS12</b></p> <p>48 22 00.0000N 013 00 00.0000E - 48 17 29.4680N 013 09 58.9780E - entlang der Bundesgrenze bis / along State Boundary to - 48 04 41.4097N 012 45 25.7328E - 47 56 03.0000N 012 43 37.0000E - 47 52 18.0000N 012 42 54.0000E - 47 55 03.0000N 012 39 51.0000E - 47 53 52.0000N 012 35 29.0000E - 47 51 17.0000N 012 34 46.0000E - 47 52 03.0000N 012 16 13.0000E - 47 50 30.0000N 012 00 00.0000E - 47 53 49.0000N 012 01 18.0000E - 48 00 00.0000N 012 30 00.0000E - 48 11 05.0000N 012 30 00.0000E - 48 22 00.0000N 013 00 00.0000E</p>
<p><b>EDS4</b></p> <p>47 46 20.0000N 011 55 00.0000E - 47 47 47.0000N 012 39 17.0000E - 47 44 03.0000N 012 46 18.0000E - 47 43 32.0927N 012 54 15.3805E - entlang der Bundesgrenze bis / along State Boundary to - 47 40 49.7456N 013 04 43.5871E - 47 37 52.0000N 012 55 43.0000E - 47 41 00.0000N 012 53 00.0000E - 47 41 00.0000N 012 46 00.0000E - 47 39 58.4577N 012 45 41.0992E - entlang der Bundesgrenze bis / along State Boundary to - 47 30 31.2392N 011 28 28.1406E - 47 46 20.0000N 011 55 00.0000E</p>
<p><b>EDS5</b></p> <p>47 50 30.0000N 012 00 00.0000E - 47 52 03.0000N 012 16 13.0000E - 47 51 17.0000N 012 34 46.0000E - 47 48 53.0000N 012 37 52.0000E - 47 47 47.0000N 012 39 17.0000E - 47 46 20.0000N 011 55 00.0000E - 47 50 30.0000N 012 00 00.0000E</p>
<p><b>EDS6</b></p> <p>47 47 00.1463N 012 56 18.3196E - entlang der Bundesgrenze bis / along State Boundary to - 47 43 32.0927N 012 54 15.3805E - 47 44 03.0000N 012 46 18.0000E - 47 47 47.0000N 012 39 17.0000E - 47 48 53.0000N 012 37 52.0000E - 47 47 00.1463N 012 56 18.3196E</p>
<p><b>EDS7</b></p> <p>47 51 46.0000N 012 50 58.0000E - 47 49 41.0000N 012 52 58.0000E - 47 47 52.0760N 012 57 42.5477E - entlang der Bundesgrenze bis / along State Boundary to - 47 47 00.1463N 012 56 18.3196E - 47 48 53.0000N 012 37 52.0000E - 47 52 18.0000N 012 42 54.0000E - 47 50 24.0000N 012 48 24.0000E - 47 51 46.0000N 012 50 58.0000E</p>
<p><b>EDS9</b></p> <p>48 04 41.4097N 012 45 25.7328E - entlang der Bundesgrenze bis / along State Boundary to - 47 52 00.6621N 012 59 22.9669E - 47 52 41.0000N 012 52 51.0000E - 47 51 46.0000N 012 50 58.0000E - 47 55 00.0000N 012 47 50.0000E - 47 52 18.0000N 012 42 54.0000E - 47 56 03.0000N 012 43 37.0000E - 48 04 41.4097N 012 45 25.7328E</p>
<p><b>LOS201</b></p> <p>47 21 11.1141N 011 03 58.5065E - 47 17 09.0000N 011 00 22.0000E - 47 17 03.1371N 010 58 39.7781E - 47 16 05.1895N 010 56 24.7727E - 47 15 00.2284N 010 55 27.5248E - 47 14 41.8764N 010 41 38.1771E - 47 19 05.9106N 010 41 24.9835E - 47 16 08.6244N 010 13 57.1401E - 47 16 12.0000N 010 10 42.0000E - 47 16 12.9026N 010 10 26.5890E - entlang der Bundesgrenze bis / along State Boundary to - 47 28 45.1359N 010 52 53.9302E - 47 21 24.2316N 010 53 26.7846E - 47 21 11.1141N 011 03 58.5065E</p>
<p><b>LOS202</b></p> <p>47 18 36.0000N 011 38 38.0000E - 47 17 53.0000N 011 34 21.0000E - 47 14 30.0000N 011 27 05.0000E - 47 13 48.0300N 011 24 06.7515E - 47 14 00.0000N 011 15 38.0000E - 47 22 00.0000N 011 07 00.0000E - 47 23 44.1754N 011 06 15.7176E - entlang der Bundesgrenze bis / along State Boundary to - 47 30 31.2392N 011 28 28.1406E - 47 28 16.5000N 011 38 47.4000E - 47 18 36.0000N 011 38 38.0000E</p>
<p><b>LOS203</b></p> <p>47 40 46.0350N 012 15 18.8835E - 47 30 17.0000N 012 11 48.5000E - 47 22 17.0000N 011 54 15.5000E - 47 22 20.0000N 011 43 40.0000E - 47 27 42.0000N 011 41 25.0000E - 47 28 16.5000N 011 38 47.4000E - 47 30 31.2392N 011 28 28.1406E - entlang der Bundesgrenze bis / along State Boundary to - 47 40 46.0350N 012 15 18.8835E</p>
<p><b>LOS204</b></p> <p>47 22 20.0000N 011 43 40.0000E - 47 18 45.1000N 011 39 31.7500E - 47 19 27.0000N 011 47 28.0000E - 47 18 15.2699N 011 50 48.4396E - 47 18 09.9250N 011 53 45.0521E - 47 20 00.0000N 011 56 37.5000E - 47 22 09.0000N 012 13 16.0000E - 47 37 31.1160N 012 30 44.1741E - entlang der Bundesgrenze bis / along State Boundary to - 47 40 46.0350N 012 15 18.8835E - 47 30 17.0000N 012 11 48.5000E - 47 22 17.0000N 011 54 15.5000E - 47 22 20.0000N 011 43 40.0000E</p>

Bezeichnung Seitliche Begrenzungen
Name Lateral limits
<p><b>LOS205</b></p> <p>47 37 31.1160N 012 30 44.1741E - 47 20 10.0000N 012 29 40.0000E - 47 20 10.0000N 012 54 50.0000E - 47 14 00.0000N 013 30 00.0000E -            47 02 45.0000N 013 41 00.0000E - 47 12 00.0000N 013 56 50.0000E - 47 25 39.9866N 013 39 52.4993E - 47 28 24.1664N 013 41 49.0275E -            47 30 48.0555N 013 40 38.6946E - 47 32 07.6867N 013 37 18.0274E - 47 31 31.6382N 013 33 07.8110E - 47 34 48.0000N 013 29 41.0000E -            47 27 14.0000N 013 29 45.0000E - 47 24 11.0000N 013 32 26.0000E - 47 20 31.0000N 013 33 37.0000E - 47 18 01.0000N 013 13 18.0000E -            47 27 14.0000N 013 13 08.0000E - 47 37 06.1061N 013 04 47.6619E - entlang der Bundesgrenze bis / along State Boundary to - 47 37 31.1160N 012 30 44.1741E</p>
<p><b>LOS206</b></p> <p>47 20 10.0000N 012 29 40.0000E - 47 20 10.0000N 012 54 50.0000E - 47 14 00.0000N 013 30 00.0000E - 47 15 57.0113N 012 51 38.9356E -            47 17 00.0000N 012 29 00.0000E - 47 20 10.0000N 012 29 40.0000E</p>
<p><b>LOS207</b></p> <p>47 02 58.2805N 011 59 39.8122E - 47 17 00.0000N 012 29 00.0000E - 47 15 57.0113N 012 51 38.9356E - 46 37 59.7431N 012 48 14.3375E - entlang der            Bundesgrenze bis / along State Boundary to - 47 02 58.2805N 011 59 39.8122E</p>
<p><b>LOS208</b></p> <p>47 28 16.5000N 011 38 47.4000E - 47 27 42.0000N 011 41 25.0000E - 47 22 20.0000N 011 43 40.0000E - 47 18 45.1000N 011 39 31.7500E -            47 19 27.0000N 011 47 28.0000E - 47 18 15.2699N 011 50 48.4396E - 47 18 09.9250N 011 53 45.0521E - 47 20 00.0000N 011 56 37.5000E -            47 22 09.0000N 012 13 16.0000E - 47 37 31.1160N 012 30 44.1741E - 47 20 10.0000N 012 29 40.0000E - 47 17 43.1794N 012 07 46.0435E -            47 17 30.0000N 012 05 50.0000E - 47 16 00.0000N 011 54 00.0000E - 47 17 25.3394N 011 45 37.4760E - 47 18 20.0000N 011 48 10.0000E -            47 18 36.0000N 011 38 38.0000E - 47 28 16.5000N 011 38 47.4000E</p>
<p><b>LOS209</b></p> <p>47 17 43.1794N 012 07 46.0435E - 47 20 10.0000N 012 29 40.0000E - 47 17 00.0000N 012 29 00.0000E - 47 17 43.1794N 012 07 46.0435E</p>
<p><b>LOS210</b></p> <p>46 59 32.8579N 011 46 54.3992E - 47 09 59.4014N 011 57 52.9796E - 47 10 45.0000N 012 07 55.0000E - 47 17 00.0000N 012 29 00.0000E -            47 02 58.2805N 011 59 39.8122E - entlang der Bundesgrenze bis / along State Boundary to - 46 59 32.8579N 011 46 54.3992E</p>
<p><b>LOS211</b></p> <p>47 17 30.0000N 012 05 50.0000E - 47 17 43.1794N 012 07 46.0435E - 47 17 00.0000N 012 29 00.0000E - 47 10 45.0000N 012 07 55.0000E -            47 09 59.4014N 011 57 52.9796E - 47 16 11.0750N 012 04 26.2411E - 47 17 30.0000N 012 05 50.0000E</p>
<p><b>LOS213</b></p> <p>47 08 00.0000N 011 32 30.0000E - 47 12 20.0000N 011 45 10.0000E - 47 13 30.0000N 011 57 30.0000E - 47 16 11.0750N 012 04 26.2411E -            47 09 59.4014N 011 57 52.9796E - 47 08 00.0000N 011 32 30.0000E</p>
<p><b>LOS214</b></p> <p>47 08 00.0000N 011 32 30.0000E - 47 09 59.4014N 011 57 52.9796E - 46 59 32.8579N 011 46 54.3992E - entlang der Bundesgrenze bis / along State Boundary to -            47 00 18.3509N 011 30 30.8180E - 47 08 00.0000N 011 32 30.0000E</p>
<p><b>LOS215</b></p> <p>46 59 32.1271N 011 19 09.6490E - 47 07 59.5560N 011 15 59.3514E - 47 07 55.0000N 011 10 05.0000E - 47 08 00.0000N 010 40 51.5200E -            47 11 28.0000N 010 28 19.0000E - 47 12 55.9411N 011 01 40.2202E - 47 13 20.1475N 011 06 54.1124E - 47 08 00.0000N 011 16 00.0000E -            47 05 06.0000N 011 21 31.0000E - 47 00 03.0000N 011 25 50.0000E - 46 58 27.9363N 011 26 08.5265E - entlang der Bundesgrenze bis / along State Boundary to -            46 59 32.1271N 011 19 09.6490E</p>
<p><b>LOS216</b></p> <p>47 28 45.1359N 010 52 53.9302E - 47 21 24.2316N 010 53 26.7846E - 47 21 11.1141N 011 03 58.5065E - 47 23 44.1754N 011 06 15.7176E - entlang der            Bundesgrenze bis / along State Boundary to - 47 28 45.1359N 010 52 53.9302E</p>
<p><b>LOS217</b></p> <p>47 03 38.7887N 009 36 25.4815E - 47 11 28.0000N 010 28 19.0000E - 47 08 00.0000N 010 40 51.5200E - 46 58 27.1741N 011 15 24.1093E - entlang der            Bundesgrenze bis / along State Boundary to - 46 51 17.6926N 010 28 10.7570E - entlang der Bundesgrenze bis / along State Boundary to -            47 03 38.7887N 009 36 25.4815E</p>
<p><b>LOS218</b></p> <p>47 11 28.0000N 010 28 19.0000E - 47 16 04.0000N 010 10 00.0000E - 47 18 08.2308N 010 02 44.7838E - 47 24 30.4272N 009 39 06.8780E - entlang der            Bundesgrenze bis / along State Boundary to - 47 03 38.7887N 009 36 25.4815E - 47 11 28.0000N 010 28 19.0000E</p>

Bezeichnung Seitliche Begrenzungen
Name Lateral limits
<p><b>LOS219</b></p> <p>47 24 30.4272N 009 39 06.8780E - 47 18 08.2308N 010 02 44.7838E - 47 16 04.0000N 010 10 00.0000E - 47 16 12.9026N 010 10 26.5890E - entlang der Bundesgrenze bis / along State Boundary to - 47 32 00.4337N 009 43 41.0052E - 47 32 21.0120N 009 33 49.4028E - entlang der Bundesgrenze bis / along State Boundary to - 47 24 30.4272N 009 39 06.8780E</p>
<p><b>LOS220</b></p> <p>46 59 32.1271N 011 19 09.6490E - 47 07 59.5560N 011 15 59.3514E - 47 07 55.0000N 011 10 05.0000E - 47 08 00.0000N 010 40 51.5200E - 46 58 27.1741N 011 15 24.1093E - entlang der Bundesgrenze bis / along State Boundary to - 46 59 32.1271N 011 19 09.6490E</p>
<p><b>LOS221</b></p> <p>47 16 12.9026N 010 10 26.5890E - 47 16 04.0000N 010 10 00.0000E - 47 11 28.0000N 010 28 19.0000E - 47 12 55.9411N 011 01 40.2202E - 47 13 20.1475N 011 06 54.1124E - 47 17 09.0000N 011 00 22.0000E - 47 17 03.1371N 010 58 39.7781E - 47 16 05.1895N 010 56 24.7727E - 47 15 00.2284N 010 55 27.5248E - 47 14 41.8764N 010 41 38.1771E - 47 19 05.9106N 010 41 24.9835E - 47 16 08.6244N 010 13 57.1401E - 47 16 12.0000N 010 10 42.0000E - 47 16 12.9026N 010 10 26.5890E</p>
<p><b>LOS222</b></p> <p>47 23 44.1754N 011 06 15.7176E - 47 21 11.1141N 011 03 58.5066E - 47 17 09.0000N 011 00 22.0000E - 47 13 20.1475N 011 06 54.1124E - 47 08 00.0000N 011 16 00.0000E - 47 05 06.0000N 011 21 31.0000E - 47 00 03.0000N 011 25 50.0000E - 46 58 27.9363N 011 26 08.5265E - entlang der Bundesgrenze bis / along State Boundary to - 47 00 18.3509N 011 30 30.8180E - 47 08 00.0000N 011 32 30.0000E - 47 12 20.0000N 011 45 10.0000E - 47 13 30.0000N 011 57 30.0000E - 47 16 11.0750N 012 04 26.2411E - 47 17 30.0000N 012 05 50.0000E - 47 16 00.0000N 011 54 00.0000E - 47 17 25.3394N 011 45 37.4760E - 47 18 20.0000N 011 48 10.0000E - 47 18 36.0000N 011 38 38.0000E - 47 17 53.0000N 011 34 21.0000E - 47 14 30.0000N 011 27 05.0000E - 47 13 48.0300N 011 24 06.7515E - 47 14 00.0000N 011 15 38.0000E - 47 22 00.0000N 011 07 00.0000E - 47 23 44.1754N 011 06 15.7176E</p>